



PROTECTION OF AIR INSULATED METAL CLAD SWITCHGEAR

Arc Fault Monitoring System 1S24

Arc fault protection to provide high speed detection and clearance of arcing faults.

- 16 Point Arc Sensors
- > 12 Point + 2 Linear Arc Sensor Version
- > 3 High speed trip outputs
- > Optic fibre or RJ45 communications
- > Suitable for simple or complex switchboards
- > Surface, DIN rail or flush mounting options
- Made in Australia





1S24 - Introduction





Figure 1: 1S24 Arc Fault Module

Description

The 1S24 relay is designed to detect the high intensity light emitted by the onset of an electrical arcing event. The 1S24 may be employed to create a comprehensive arc fault protection system comprising the following components:

Optical sensor

1S30 point sensors and 1S40 linear sensors are available to provide wide detection coverage within metal clad switchgear, cable compartments and bus bars.

Arc Flash Monitor

The 1S24 also takes care of sensor supervision and allows for direct tripping of circuit breakers for high speed clearance of arcing faults.

Arc Fault Protection

Arc fault protection is a relatively new technique employed for the clearance of arcing faults on low voltage panels, MCC's, BUS bars and within metal clad switchgear and associated cable boxes.

Conventional current based protection techniques are at times challenged by the nature of arcing faults, and can result in slow protection clearance times. Slow protection clearance times increase the risk to nearby personnel and increase the degree of damage to plant and equipment.

By employing an optical detection technique, Arc Fault Protection results in fast clearance of arcing faults.

Features

- Up to 16 arc fault sensors
- > 16 point or 12 point + 2 linear arc sensors
- > High speed arc fault tripping duty contacts
- > Trip indication LED for each arc fault sensor
- Arc sensor supervision with sensor fail LED for each zone
- > 10Base-T / 100Base-TX port
- Optional 100Base-FX port
- > System configuration via web browser
- Self-supervision watchdog with healthy LED and alarm contact
- > Wide range auxiliary supply
- > Surface mount or flush mount options




Figure 2: Energy release due to electrical arcing faults

1S24 - Arc Fault Protection



Arc Fault - Cause and Effect

Medium voltage switchgear and associated bus bars are a key element in the power supply chain. Existing protection systems operate effectively and quickly under most fault types but arcing faults may lead to slow operating times.

Due to the resistive nature of an arcing fault the associated fault current is likely to be lower than for a bolted short circuit.

Instantaneous overcurrent protection is set to operate above network energization currents and motor starting currents, the fault current due to an arc may be lower than this.

The consequence of these conditions is that a protection system based solely on over-current detection cannot effectively discriminate between normal system currents and an arc fault condition:

- Moderate to low arc fault currents may not operate the instantaneous trip stage of a standard over-current relay
- For a Moderate to low arc fault current the trip time of the over-current IDMT stage will be too slow

Arcing faults in metal clad switchgear and associated Bus bars may occur for a number of reasons:

- defective or ageing insulating materials
- poor bus or cable connections
- poor maintenance
- human error
- ingress of moisture, dust or vermin
- abnormal service conditions

The degree of damage caused by arcing depends principally on the duration of the arc. If an arc lasts only 100ms, the switchgear needs to be checked and the insulation resistance measured before power can be re-established. With a 200ms arc, the power supply will be interrupted; the switchgear must be checked; power is re-established only after minor repairs. In the event of a 500ms arc the supply is interrupted; metal parts of the switchgear are destroyed and poisonous gases are emitted. A 1s arc destroys most of the switchgear and may cause a fire, injury to personnel and damage to property.

Arc Flash Detection Principal

An arcing fault results in an intense and rapid discharge of light from the arcing source. The light discharged from an arcing fault will typically be several thousand times normal ambient lighting levels.

The 1S24 ARC Fault Detection system optically senses the presence of an ARC by the means of 1S30 optical sensors connected to the 1S24 monitor.

Very fast ARC detection is achieved using this technique, and protection operation times of <10ms are achievable.

Arc Sensor Location

The number and location of optical arc sensors is dictated by the switchgear and Bus bar design and the length of the switchboard.

In most indoor metal clad switchgear, the bus bar chamber is a continuous chamber between panels only broken into segregated sections at a bus section breaker and as such the strategic placement of one or two arc sensors in each bus bar chamber run is normally adequate.

Some indoor metal clad switchgear may segregate the bus chamber of each panel from the next via insulated bus chamber side barriers per panel, if this is the case then each bus chamber per panel would need to be monitored by at least one arc sensor.

Isolating switches between BUS bar sections need to also be considered and appropriate tripping zones created to ensure isolation of the faulted section.

In large enclosures the arc sensors should be placed at approximately 3-5m intervals. 1S30 arc sensors are also available with dual optical detectors to allow detection of an arc in both directions.

Arc Fault Protection with Current Check

For system security purposes, the optical ARC detection may also be supervised by an external Instantaneous Current Check element to confirm fault detection.




Figure 3: High speed AND logic employed to discriminate an

Arc fault protection compliments existing conventional overcurrent and differential protection schemes and is easily implemented into both new and existing installations.



Figure 4: Consequences of arcing faults



Web Based Configuration

Configuration of the 1S24 Arc Fault Monitor is carried out using a web browser interface as depicted in the screen shots shown in figures 5 and 6. Connection is made between the 1S24 and a PC using a standard Category 5 patch cable with RJ45 electrical plugs.

Connect the 1S24 port P1 to the PC Ethernet LAN port.

Open a PC browser using the default IP address 192.168.0.220

Ethernet Configuration

The current status of the relay comms. configuration is shown.

SNTP Server Change SNTP server name

(SNTP server of the Station Bus Lan)

SNTP re-sync. Changes re-sync. time in seconds
Password Change administration password

Any changes are password protected and require entry of the Username (admin) and the Password (Default from the factory is RMS).



Figure 5: 1S24 IP Configuration screen

Arc Configuration Screen

The current status of each ARC detector is shown. To make the web page follow the ARC status in real time, tick the Automatic refresh button.

Arc Configuration

Each individual ARC sensor can be configured as follows: Armed or Disabled by clicking on the state column.

Arc States

The following list defines the possible ARC states:

> Disabled: Sensor not connected or disabled

> Armed: Ready to detect an ARC fault> Failed: ARC sensor supervision failure

> Tripped: ARC detected

> Initializing: ARC sensor initializing (transitory)

> Stuck: ARC sensor stuck on

> Included: Determines whether a sensor is allocated to the

relay

> Trip outputs (Yes or No)

Each individual ARC sensor provides the following status:

> Trip: Indicates when the ARC LED Flag is asserted (Yes

or No)

> Count: Retains a count since power on of how many

times ARC sensor has been tripped. This count can be reset to 0 by clicking on the counter.




Figure 6: 1S24 Arc Sensor Configuration screen



Arc Sensor Function

The 1S30 is an optical sensor that responds to the flash of light emitted during the incidence of an arcing fault. Onset of the light flash and detection by the 1S30 occurs in a few ms.

Refer to the 1S30 Technical Bulletin for further details.

1S30 Point Sensor Inputs and Indicators

A red LED is provided for each arc sensor input to indicate:

Trip: LED illuminates solid on detection of an arc fault.

Resets when the front panel reset button is pressed or voltage pulse applied to remote reset status input. Individual flags can also be observed and cleared via the device web server.

Fail: LED Flashes to indicate failure of 1S30 Arc Fault Sensor in zone.




Figure 7: Point arc sensor LED's and terminals

1S40 Linear Sensor Inputs

Two 1S40 linear sensor connection ports are provided where this option is specified.



Figure 8: Linear arc sensor connection ports

Auxiliary Supply

A single green LED is provided to signal when an auxiliary supply is connected and the 1S24 energised.



Figure 9: Auxiliary supply healthy LED

Arc Trip Output Contacts

The 1S24 provides two (2) or three (3) high speed tripping output contacts. These may be employed for local tripping functions and for system testing purposes. Each sensor input may be set to trip either of the output contacts.

The arc trip contacts will self-reset after a 2s delay. The trip indication LED is reset either by pressing the front panel reset button, via the remote reset status input or via the device web server.



Figure 10: Arc trip output contacts and trip LED

Arc Trip Blocking Input

The 1S24 provides a status input to enable a global block of all arc fault detection sensors. Application of a control voltage within the specified range will activate this function and energize the Global Arc Block LED.



Figure 11: Global arc block input and LED indication

Arc Detection Reset Time

Effect of multiple arc trips

A delay of 2s is required to reset the 1S24 after an initial arc sensor trip. Subsequent arc detection will cause the trip outputs to re-operate.

Remote Reset

A remote reset status input is provided to reset the arc trip LED's.



Figure 12: Remote reset binary input and flag reset



1S30 Point Sensor Supervision

To monitor the integrity of the wiring between the 1S30 arc sensor and 1S24 Arc Monitor, continuous 2mA supervision current flows between the units.

If the sensor supervision current is not detected for 1s the Sensor Alarm contact will operate and the Sensor Alarm LED will illuminate solid.

The affected sensor(s) will be indicated by the front panel sensor LED 1-16 flashing.

1S40 Linear Sensor Supervision

To monitor the integrity of the 1S40 arc sensor a periodic light pulse is transmitted from the 1S24 Tx port. This light pulse travels the length of the 1S40 linear sensor and is received at the 1S24 Rx port to confirm the integrity of the 1S40 sensor. Internal logic is employed in the 1S24 to ensure that arc trips are masked during the self-test cycle.

If the return pulse is not detected the Sensor Alarm contact will operate and the Sensor LED flash.

The 1S40 arc sensors are automatically calibrated at system power up. If the calibration process fails, the Cal LED will be illuminated and the Trip LED flash indicating an alarm condition.

Refer to the 1S40 Technical Bulletin for details on how to configure the 1S24 for correct operation.




Figure 13: Front panel 1S40 linear sensor LED's

The status of the linear sensors is indicated by the four (4) LED's on the 1S24 front panel as per table 1.

1S40 Sensor LED's				
Sensor 13		Sensor 14		
13	Cal	14	Cal	
Flash	Solid	Flash	Solid	Calibration Fail
Flash	-	Flash	-	Sensor Fail Alarm
Solid	-	Solid	-	Arc Trip

Table 1

Arc Sensor Continuously Picked Up

High ambient light levels may cause a 1S30 or 1S40 to be continuously picked up. This condition could occur for example if the CB cable box cover was left open in very high ambient light level conditions. A non-arc fault over-current pick up would then result in an arc fault trip operation.

To avoid possible mal operation due to this condition, the 1S24 is designed to automatically disable the arc fault tripping function if the 1S30 or 1S40 sensor is picked up for >10s. The 1S24 Sensor Alarm contact will operate and Sensor Alarm LED will illuminate solid until the ambient light level problem is corrected. The 1S24 will then perform an arc sensor test function and automatically reset

The effected sensor(s) will be indicated by the front panel sensor LED 1-16 flashing.

Sensor Fail Alarm

A common Sensor Fail Alarm contact is provided.




Figure 14: Sensor fail alarm LED and output contact

Self-Supervision Service Alarm

A C/O alarm contact is maintained in the energized state when all of the following conditions are met:

The auxiliary supply is applied

The internal 5V DC rail is within acceptable limits

The CPU hardware watchdog maintains a pulsing output

The Service Alarm LED will be energized for a CPU fail condition.



Figure 15: Self-supervision service alarm



Rating Plate and Flag Reset

The rating plate is clearly identified on the front panel.

A reset button is provided to reset the arc trip LED's.

This button also has other functions to initiate warm boot and cold boot to restore factory default settings. Refer to the User Guide for details.



Figure: 16: Relay rating plate and reset button

Customer Labelling

The 1S24 front panel has provision for two (2) custom labels. Custom labels may be produced using the template provided on the RMS web, printed and slipped behind the clear windows on the front panel as depicted below.

Alternatively, the default label may be marked up by hand.

This allows identification of arc sensor positions and details such as the 1S24 IP address.

https://www.morssmitt.com/uploads/files/catalog/products/1s 24-slide-label-template(1).docx



Figure 17: Slide in label for 1S24 location and IP address



Figure 18: Slide in label for arc sensor location

Ethernet Communication Port(s)

The 1S24 provides two (2) high speed Ethernet port options for connection to a local area network (LAN).

Standard Port

The standard port employs an electrical interface with an RJ45 connector and supports 10Base-T / 100Base-TX. The port may be utilised for device configuration.

Optional Second Port

An optional second port employs a plug-in optical fibre port and supports 100Base-FX.

Either port may be utilised for device configuration.



Figure 19: Standard single port 10Base-T / 100Base-TX



Figure 20: Optional dual port 10Base-T / 100Base-TX + 100Base-FX

Communications Status

LED's are provided to indicate auxiliary supply and Ethernet activity.



Figure 21: System status LED's

Chassis Earth



Figure 22: Chassis earth terminal

1S24 - Technical Data



Auxiliary Supply

Low Range Version	Order Code A
Nominal dc Voltage Supply	48
Standards Compliant Range (Shown on relay front panel)	40-58V dc
Absolute Range	20-70V dc
High Range Version	Order Code B
Nominal dc Voltage Supplies	110 / 125 / 220 / 240 / 250
Standards Compliant Range (Shown on relay front panel)	62-250V dc 44-230V ac 50/60 Hz
Absolute Range	40-300V dc 40-275V ac 50/60 Hz
Burden - Quiescent	8W at 110V dc
Burden - Maximum	15W at 110V dc

Binary Inputs

Operating Range	18-275V ac / 17-290V dc
Operating Current	10mA pickup for 1ms
	Reducing to 1.5mA after 4ms
DC Operate Time	<4ms pickup
	<16ms dropout
AC Operate Time	<23ms pickup
	<33ms dropout
Function	Enable on the application of the control voltage

Standard Trip Outputs

Voltage free
Self-reset
8-9ms (Flash to contact closure)
2s
5A ac or dc
20A ac or dc for 0.5s
30A ac or dc for 0.2s
L/R ≤ 40ms and ≤ 300V
1,250VA
250VA at p.f. \leq 0.4
75W
30W at L/R \leq 40ms
50W at L/R \leq 10ms
100mA ≥12V

Hybrid High Speed Trip Output Option

Specifications as per the standard trip outputs except:		
Switching Polarity DC only		
Trip Contact Operate Time	<2.2ms (Flash to contact closure)	
Reset Time	2s	
Breaking Capacity	20A dc	

Arc Fault Point Sensor Inputs

Number	12 or 16
Туре	1S30 point sensors
Connection	Electrical termination
Zones	Up to 16
Supervision duration	Continuous

Arc Fault Linear Sensor Inputs

Number	0 or 2
Туре	1S40 linear sensors
Connection	Rx and Tx optic fibre ports
Zones	Up to 2
Supervision duration	<1ms
Supervision interval	Settable to 1, 2, 5, 15 or 30 min.

1S24 - Compliance Data



ELECTRICAL ENVIRONMENT

AC and DC Voltage Dips

Standard	IEC 60255-26, #7.2.11
Test Level	Test specification
Dip to 0% of residual voltage	DC: 20 ms
Acceptance criterion A	AC: 1 cycle 50/60 Hz
Dip to 40% of residual voltage	DC: 200 ms
Acceptance criterion C	AC: 10/12 cycles 50/60 Hz
Dip to 70% of residual voltage	DC: 500 ms
Acceptance criterion C	AC: 25/30 cycles 50/60 Hz

AC and DC Voltage Interruptions

Standard	IEC 60255-26, #7.2.11 Acceptance criterion C
Test Level	Test specification
Drop to 0% of residual voltage	DC: 5 s AC: 250/300 cycles 50/60 Hz

AC Component in DC (Ripple)

Standard	IEC 60255-26, #7.2.12 Acceptance criterion A
Test Level	Test specification
15% of rated DC value	100/120 Hz, Sinusoidal

Gradual Shut-down/Start-up (DC Power Supply)

Standard	IEC 60255-26, #7.2.13 Acceptance criterion C
Test Identification	Test specification
Shut-down ramp	60 s
Power off	5 min
Start-up ramp	60 s

Clearances and Creepage Distances

Standard	IEC 60255-26, #10.6.3
Test Identification	Test specification
Pollution degree	2
Overvoltage category	III
Rated insulation voltage	300 V rms or d.c.
Clearances and Creepage Compliance	CAD drawings assessment

Safety-related Electrical Tests

Standard	IEC 60255-27, #10.6.4
Test Identification	Test specification
Between Independent Circuits	5 kV 1.2/50 μ s 0.5 J 3 pulses of each polarity 2.0 kV ac rms for 1 minute
Any Terminal and Earth	5 kV 1.2/50 μ s 0.5 J 3 pulses of each polarity 2.0 kV ac rms for 1 minute
Across Normally Open Contacts	1 kV ac rms for 1 min
Protective Bonding Resistance	< 0.1 Ω at 20 A

Electrical Environment and Flammability

Standard	IEC 60255-27, #10.6.5
Test Identification	Test specification
Single-fault condition	Assessment
Maximum temperature of	Metal parts: < 70°C
accessible parts at ambient temperature +40°C	Non-metallic parts: < 80°C
Flammability of insulating materials, components and fire enclosures	Assessment

Reverse Polarity and Slow Ramp Test

Standard	IEC 60255-27, #10.6.6
Test Identification	Test specification
Maximum voltage d.c.	V start-up + 20%
Minimum voltage d.c.	V shutdown - 20%
Ramp down/up gradient	1 V/min

1S24 - Compliance Data



ATMOSPHERIC ENVIRONMENT

Temperature

Standard	IEC 60068-2-1, IEC 60068-2-2	
Test Identification	Test specification Auxiliary power Supply voltage	
Operating Range	-10 to +55°C Min and Max	
Storage Range	-25 to +70°C Non-energized	
Test duration	16 h at top and bottom temperatures	

Damp Heat (Humidity)

Standard	IEC 680068-2-78
Test Identification	Test specification
Operating Range	40°C and 93% RH non-condensing
Test duration	16 h

IP Rating

Standard	IEC 60529
Test Identification	Test specification
Installed	Enclosure: IP5x
Installed	Terminals: IP1x

MECHANICAL ENVIRONMENT

Vibration - Sinusoidal

Standard	IEC 60255-21-1 Class 1	
Test Identification	Test specification	Variation
Vibration Response in each of 3 axes	0.035 mm/0.5 gn peak 1 sweep cycle 10-150 Hz	No Mal-Op
Vibration Endurance	1.0 gn peak	Non-
in each of 3 axes	20 sweep cycles 10-150 Hz	energized

Shock and Bump

Standard	IEC 60255-21-2 Class 1	
Test Identification	Test specification	Variation
Shock Response in each of 3 axes	5 gn, 11 ms, 3 pulses in each direction	No Mal-Op
Shock Withstand in each of 3 axes	15 gn, 11 ms, 3 pulses in each direction	Non- energized
Bump Test in each of 3 axes	10 gn, 16 ms, 1,000 bumps in each direction	Non- energized

Seismic

Standard	IEC 60255-21-3 Class 1	
Test Identification	Test specification	Variation
Seismic Response Horizontal, on each axis	3.5 mm/1.0 gn, 1 sweep cycle 1-35Hz	No Mal-Op
Seismic Response Vertical	1.5 mm/0.5 gn, 1 sweep cycle 1-35Hz	No Mal-Op

1S24 - Compliance Data



ELECTROMAGNETIC COMPATIBILITY (EMC)

IMMUNITY

Electrostatic Discharge (ESD)

Standard	IEC 60255-26, #7.2.3, Acceptance criterion B	
Port	Enclosure	
Test Identification	Test specification Variation	
Contact Discharge	6 kV	No Mal-Op

Radiated Electromagnetic Field

Standard	IEC 60255-26, #7.2.4, Acceptance criterion A	
Port	Enclosure	
Test Identification	Test specification	Variation
Frequency sweep	10 V rms, 80 to 1000 MHz 1400 to 2700 MHz	No Mal-Op
Spot frequencies	10 V rms, 80, 160, 380, 450, 900, 1850 & 2150 MHz	No Mal-Op

Fast Transients (EFT)

Standard	IEC 60255-26, #7.2.5, Acceptance criterion B	
Port	Auxiliary power supply, Input and Output, Functional Earth	
Test level	Test specification	Variation
Zone A	4 kV peak, 5/50 ns, 5 kHz	No Mal-Op

Slow Damped Oscillatory Wave (HFD)

Standard	IEC 60255-26, #7.2.6, Acceptance criterion B	
Port	Auxiliary power supply, Input and Output	
Test Identification	Test specification	Variation
Common Mode	1 MHz 2.5 kV peak	No Mal-Op
Differential Mode	1 MHz 1.0 kV peak	No Mal-Op

Surge

Standard	IEC 60255-26, #7.2.7, Acceptance criterion B	
Port	Auxiliary power supply, Input and Output	
Test Identification	Test specification	Variation
Line-to-earth	4 kV peak	No Mal-Op
Line-to-line	2 kV peak	No Mal-Op

Conducted Disturbance Induced by RF Fields

Standard	IEC 60255-26, #7.2.8, Acceptance criterion A	
Port	Auxiliary power supply, Input and Output, Functional Earth	
Test Identification	Test specification	Variation
Frequency sweep	10 V rms, 0.15 to 80 MHz	No Mal-Op
Spot frequencies	10 V rms, 27 & 68 MHz	No Mal-Op

Power Frequency Magnetic Field

Standard	IEC 60255-26, #7.2.10
Port	Enclosure only
Test Identification	Test specification
Continuous ≥ 60 s	30 A/m - Acceptance criterion A
Short time 1 s to 3 s	300 A/m - Acceptance criterion B

EMISSION

Emission Enclosure

Standard	IEC 60255-26, #5.1	
Test Identification	Frequency range	Limits, dB (μV/m)
Radiated emission	30 - 230 MHz	40, quasi peak at 10 m 50, quasi peak at 3 m
<1 GHz	230 - 1000 MHz	47, quasi peak at 10 m
		57, quasi peak at 3 m
Radiated emission	1 – 3 GHz	56, average
Radiated emission		76, peak at 3 m
>1 GHz 3 – 6 GHz	3 – 6 GHz	60, average
		80, peak at 3 m

Emission Auxiliary Power Supply Port

Standard	IEC 60255-26, #5.2	
Test Identification	Frequency range	Limits, dB (μV/m)
Conducted emission	0.15 – 0.50 MHz	79, quasi peak 66, average
	0.5 - 30 MHz	73, quasi peak 60. average

1S24 - Front Panel






Figure 23: Front panel layout

Rack Mount Version

1S24 Arc Fault Monitor Action of the control of th

Figure 24: Front panel layout - 12U wide including right angle RJ45 plug / socket



Figure 25: Rear terminal layout (Note the right angle RJ45 plug / socket fitted)

Flush Mount Vertical Orientation




Figure 26: Vertical front panel layout

1S24 - Wiring Diagram



Wiring and Termination

Figure 27 shows the wiring diagram for the 1S24 with 16 point sensors and 3 high speed trip outputs.

For models with 2 trip outputs, the output on terminals 10 and 11 operates as a N/O Arc Trip Block Repeat contact.

Details of the linear sensor connections are shown under the 1S40 Linear Fibre Sensor section – refer figures 23, 30 and 31.

Sturdy M3.5 screw terminals are provided suitable for one or two ring terminals. Multiple chassis earthing points are also provided.

Terminal numbering is clearly identified and graphics provided on the front panel to indicate the connection function.




Figure 27: Wiring diagram – Relay de-energized

1S24 - Arc Sensors



1S30 Point Sensor Connection

12 or 16x 1S30 point arc sensor inputs are provided.

Each sensor operates independently with a common connection shared between each pair of sensors to reduce the total number of terminals required.

Each sensor pair is wired to 3 M3 terminal screws with the centre screw being common.

Figure 27 shows the wiring arrangement. The 1S30 sensor wires are colour coded but are not polarity sensitive.



Figure 28: 1S30 sensors

1S30 Shielded Cables

Shielded cables are recommended when the length of the 1S30 cable connections exceed 6m.

M3 earth studs with nuts and lock washers are provided on the 1S24 chassis in two (2) positions - one to the left of terminal 1 and one to the right of terminal 24 - to allow connection of the optional 1S30 sensor cable shields. Refer to figure 29 for connection details.





Figure 29: 1S30 sensor wiring using shielded cables

1S40 Linear Fibre Sensor

The 1S24 may be optionally specified to interface two 1S40 linear optic fibre sensors.

The 1S40 linear sensor may be applied to protect large volumes where multiple point sensors would otherwise be required. A separate 1S40 sensor is required for each protection zone.

Refer to the 1S40 Technical Bulletin for details on how to configure the 1S24 for correct operation.



1S40 Linear Fibre Connection

When fitted, optical sensor connections 13 and 14 replace electrical terminals 43 to 48.

1S40 sensor 1: 13 - Tx 1 Cal - Rx 1 1S40 sensor 2: 14 - Tx 2 Cal - Rx 2




Figure 31: 1S40 Rx and Tx optic fibre connections

1S24 - Arc Sensors




1S40 Linear Fibre Sensor Configuration

The 1S24 arc monitor must be configured with the correct setting corresponding to the length of the optic fibre transmission section shown in figure 32 and listed in Table 2. The transmission section fibre must be cut to one of the set lengths as specified in Table 2 within a tolerance of 10%.

Configuration is achieved via the 1S24 web browser Fibre Loop Sensor Configuration screen as per figure 33.

Transmission Section Length	Setting
0 metres	<1
1 metres	1m
5 metres	5m
10 metres	10m
20 metres	20m
30 metres	30m
40 metres	40m

Table 2



1S40 Component Function and Installation Limitations




Figure 33: Fibre Loop Sensor Configuration Screen

1S24 - Dimensions



Surface or DIN Rail Mounting




Figure 34: Surface and DIN Rail mount version dimensions

1S24 - Dimensions



Panel or Rack Mounting




Figure 35: Flush and rack mount version dimensions

1S24 - Accessories



DIN Rail Mounting Kit

The 1S24 has provision to fit two (2) DIN rail mounting kits. The 1S24 may be ordered with the DIN rail kits fitted or ordered separately for fitment by the installer as per figure 36.

2x RMS P/N: 290407157 required.

Rack Mount Blanking Plate Kit

Rack mount versions are supplied with blanking plates to increase the 1S24 module with to standard 12 units wide as per figure 37.

- 1x Blanking plate
- 1x Blanking plate with cut-out for RJ45 socket
- 1x Right angle RJ45 plug / socket

Accessories Supplied with Each Relay

4 x M4 self-threading mounting screw kit

1 x Product Test Manual

1x Blanking plate kit for rack mount versions

1S30 Arc Fault Point Sensors

The 1S30 sensors are ordered separately.

Refer to the 1S30 Technical Bulletin for details.

1S40 Arc Fault Linear Sensors

The 1S40 sensors are ordered separately.

Refer to the 1S40 Technical Bulletin for details.



Figure 36: Fitting the DIN rail mounting kits




Figure 37: Rack mount version showing RJ45 socket fitted

1S24 - Order Codes



1S24 Relay Order Code





RMS Mors Smitt 19 Southern Court Keysborough, VIC 3173, Australia Tel: +61 (0)3 8544 1200 sales.rms@wabtec.com



Wabtec Netherlands B.V. Darwinstraat 10 6718 XR Ede, Netherlands Tel: +31 (0)88 600 4500 sales.msbv@wabtec.com



Visit www.morssmitt.com/rms for the latest product information.

Due to RMS continuous product improvement policy this information is subject to change without notice