

Auxiliary Flag Relays

RMS	Alstom	Reyrolle	Functional Description	Contacts	6R MATRIX	Case
6RA11	MVAA11	AR101, AR111, AR131	Auxiliary flag relay – 1 element Self-reset contacts / Hand reset flag	6	6RM202	2M28
6RA12	MVAA12	AR114, AR124	Auxiliary flag relay – 1 element Self-reset & hand reset contacts Hand reset flag	6	6RM204	2M28
6RA13	MVAA13	AR112	Auxiliary flag relay – 1 element Hand reset contacts & flag	6	6RM206	2M28
6RA15	MVAA15	AR103, AR113	Auxiliary flag relay – 1 element Hand & electrical reset contacts Independent hand reset flag	6	6RM211	2M28
6RA20	-	AR131, AR141, AR231, AR241	CT Shorting relay		6RM206 / 7	2M28 / 4M28
6RA23	MVAA23	AR212	Auxiliary flag relay – 2 element Hand reset contacts & flag	6 x 2	6RM206 x2	2M28

Trip Circuit Supervision Relays

RMS	Alstom	Reyrolle	Functional Description	Contacts	6R MATRIX	Case
6RX11	MVAX11		Trip relay circuit supervision	2	1TM13	2M28
6RX12	MVAX12	XR152, XR153	Trip supply supervision	2	1TM11	2M28
6RX21	MVAX21	XR250, XR251	Trip circuit supervision	2	1TM10	2M28
6RX31	MVAX31	XR350, XR251	Trip circuit supervision – 3 element	2	1TM12	4M28