

# V26 socket - Crimp terminal, panel mount

## Datasheet



### Description

The V26 is a panel mount relay socket with one terminal per relay contact. The wires are crimped on separate crimp contacts A260 for insertion after crimping.

To prevent fault relay placement the socket can be equipped with mechanical keying to accept only designated identical keyed relays.

### Application

The V26 relay socket is suitable for general industrial applications with a space saving design. Installation and replacement of relays is made easy and cost saving. No maintenance is required for the user.

Suitable for all D-relay series.

### Features

- Panel mount
- Crimp contacts
- Space saving
- Suitable for all D-relay series
- Positive mechanical keying
- Clear terminal ID

### Benefits


- Proven reliable
- Long term availability
- Easy to maintain
- Low life cycle cost
- No maintenance

### Industry compliancy

- EN 60947-5-1 - Electromechanical control circuit devices and switching elements
- IEC 61810 - Electromechanical elementary relays

# V26 socket


## Technical specifications



### Technical characteristics

Contact rating	10 A
Dielectric strength	IEC 60255 / IEC 60571, 2500 V, 50 Hz, 1 min
Protecting category	IEC 60529
Mounting	Panel mount
Max. ambient temperature	80 °C
Weight	38 g including 14 crimp contacts A260
Dimensions	40 x 40 x 25.5 mm
Wire diameter	Core 1.3 to 2.0 mm, isolation 3.0 to 4.6 mm
Material	Polyamide 66, 30% glas
Socket contacts	Crimp contacts
Max. torque value mounting screws	1 Nm
Accessories	A104 Key receptacle A260 Crimp contact Crimptool for A260 A261 Contact remove tool
Remark	To achieve an optimum shock & vibration (relay/socket) assembly, we recommend to insert all 14 A260 crimp contacts in the V26 socket


### Connection diagram



# V26 socket

## Technical specifications


### Dimensions



# V26 socket

## Technical specifications

V97 Faston terminal relay socket for 8 contact relays (D8 or KDN series)




For details see datasheet V97.

# V26 socket

## Technical specifications

### Mechanical keying relay and socket (optional)



Function:


- To prevent wrong installation
- To prevent damage to equipment
- To prevent unsafe situations

Using keyed relays and sockets prevents a relay being inserted in a wrong socket. For example it prevents placing a 24 VDC relay in a 110 VDC circuit. Positive discrimination is possible per different function, coil voltage, timing, monitoring, safety and non-safety.

The D-relay socket keying option gives  $8 \times 8 = 64$  possibilities. Upon ordering the customer simply indicates the need for the optional keying. Mors Smitt will assign a code to the relay and fix the pins into the relay. The sockets are supplied with loose key receptacles. Inserting the keys into the socket is very simple and self explaining.


Remark: socket and relay type are only examples.

Top view socket



Example keying position G-Z on socket

Bottom view relay



Example keying position G-Z on relay



# V26 socket

## Technical specifications

### Installation & inspection

#### Installation


Before installation or working on the relay: disconnect the power supply first!

Install socket and connect wiring according to the terminal identification. Plug relay into the socket ensuring there is no gap between the bottom of relay and the socket. Reverse installation into the socket is not possible due to the mechanical blocking snap-lock feature.

No external retaining clip needed as the 'snap-lock' will hold the relay into the socket under all circumstances and mounting directions (according shock & vibration requirements IEC 61373, Category I, Class B, Body mounted). If regulations require an external retaining clip, this is available as well. For more information see the datasheet of the retaining clips.

#### Warning!

- To remove relays from the socket, employ up and down lever movements. Sideway movement may cause damage to the coil wires.



When plugging the relay into the socket, the female bifurcated receivers will automatically cut through the corrosion on the pins and guarantee a reliable connection.

#### Inspection


If the socket does not work after inspection of the correct wiring and relay connection, replace the unit with a similar model.

When returning products for investigation, please provide all information on the RMA form. Send defective products back to the manufacturer for repair or replacement. Normal wear and tear or external causes are excluded from warranty.



# V26 socket

## Technical specifications



Article nr	Code	Description
328400100	V26	Crimp terminal relay socket
338400100	V97	Crimp terminal relay socket for 8 contact relays
378690100	A104	Key receptacle
500220000	A260	Crimp contact
339940305	-	Crimptool for A260 (AMP 674655)
339940300	A261	Contact remove tool





Mors Smitt France SAS

Tour Rosny 2, Avenue du Général de Gaulle,

F - 93118 Rosny-sous-Bois Cedex, France

T +33 (0)1 4812 1440, F +33 (0)1 4855 9001

E [sales@msrelais.com](mailto:sales@msrelais.com)

Mors Smitt Asia Ltd.

# 807, Billion Trade Centre, 31 Hung To Road

Kwun Tong, Kowloon, Hong Kong

T +852 2343 5555, F +852 2343 6555

E [info@morssmitt.hk](mailto:info@morssmitt.hk)

Mors Smitt B.V.

Vrieslantlaan 6, 3526 AA Utrecht,

Netherlands

T +31 (0)30 288 1311, F +31 (0)30 289 8816

E [sales@nieaf-smitt.nl](mailto:sales@nieaf-smitt.nl)

Mors Smitt Technologies inc.

420 Sackett Point Road

North Haven, Ct 06473, USA

T +1 (203) 287 8858, F +1 (888) 287 8852

E [mstechnologies@msrelais.com](mailto:mstechnologies@msrelais.com)

Mors Smitt UK Ltd

Doulton Road, Cradley Heath

West Midlands, B64 5QB, UK

T +44 (0) 1384 567 755, F +44 (0) 1384 567 710

E [info@morssmitt.co.uk](mailto:info@morssmitt.co.uk)